

# Installation Instructions for

**Mossberg 500/600 • Winchester 1200/1300 • Remington 870**

1. Remove the butt plate or recoil pad from the rear of the stock by unscrewing the two mount screws.
2. Insert a long flat-blade screwdriver into the hole in the rear of the stock and remove the long stock screw.
3. Remove the stock from the shotgun and replace it with the rear Tactical Grip using the supplied washer and allen-head cap screw.
4. This grip has a molded loop for sling attachment.