The templates below are for models: 500, D750, D752, SC100
For complete installation instructions and important dimensions,
please refer to the information on the recoil pad package

Small Pad

1.68 Pad Width
1.32 Insert Width
2.87 Hole Spacing
3.77 Insert Length
5.30 Pad Length

Medium Pad

1.80 Pad Width
1.45 Insert Width
3.12 Hole Spacing
3.97 Insert Length
5.50 Pad Length

Large Pad

1.92 Pad Width
1.57 Insert Width
3.12 Hole Spacing
4.50 Insert Length
5.75 Pad Length